



DR 300

Wartungs-Anleitung • Maintenance Instructions Instructions de entretien

W1 Funktionskontrolle • Checking functions Contrôle de fonctions




W2 Filtereinsatz reinigen • Cleaning self-flushing filter Nettoyer le filtre




W3 Pilotventil austauschen • Replace pilot valve

Changer la vanne pilote



W4 Innenteile austauschen • Replace inner Parts

Changer les pièces intérieures



Honeywell

Automation & Control Products

Honeywell AG
Hardhofweg
D-74821 Mosbach

Phone: (49) 6261 810
Fax: (49) 6261 81309
braukmann@honeywell.com

www.honeywell.de/haustechnik
http://europe.hbc.honeywell.com